



JASON-RANHEIM COMPANY

580 Parrott Street
(408) 287-0259

San Jose, California 95112
(408) 287-0264

PCC-8 BANK SWITCHING EPROM CARTRIDGE BOARD FOR THE C64

DIRECTIONS FOR USE

The PCC-8 is designed for use with 2764's, 27128's, 27256's (with minor board mod. as described below) and pin compatible types such as the 5133, 5143, X2864AD, etc. From one to eight EPROM's may be used in any combination of types, giving from 8k to 256k of ROM capacity in the cartridge in 8k increments. Any 8k segment of ROM can be switched into the \$8000-\$9FFF (32768-40959) address space of the computer by storing the appropriate number into the bank select register in the cartridge. In addition, ROM can be switched out completely and 8k of computer RAM is available instead.

Bank Select Register. This register (BSR for short) is a 6 bit write only register located at \$D1FF (57343). The address of the BSR may be changed to \$DEFF (57087) as described below, to avoid conflict with other cartridges, interfaces, etc. which may be plugged into the cartridge port at the same time.

There are eight sockets on the board, numbered from 0 to 7 as shown below. The active socket is selected by bits 2,3, and 4 of the BSR data. If the selected socket contains a 2764, then data bits 0 and 1 of the BSR have no effect. If the selected socket contains a 27128, then bit 0 of the BSR data controls whether the lower or upper half of the 27128 is selected. (Bit zero acts like A_{13}). If the selected socket contains a 27256, then bit 1 of the BSR data selects the lower or upper half of the 27256 (bit one acts like A_{14}), while bit zero selects the lower or upper quarter within the selected half.

Bit five of the BSR data controls the EXROM line. A one here deselects ROM and restores the underlying 8k of RAM.


On power up, the BSR is reset to ZERO. Therefore, if the cartridge is to auto-start, bank zero must contain the initial ROM.

"Peeking" the BSR resets it to ZERO.


27256 Modification. At each socket where a 27256 is to be used, make the modification shown on the next page. Carefully cut through the trace connecting pins 27 and 28 of the socket. Scrape the solder mask material from the surface of the split trace and bridge with a 'blob' of solder. To use the socket again with a 2764 or 27128, undo the modification desoldering and resoldering as necessary.

BSR CONTENTS

BIT 7 6 5 4 3 2 1 0




BANK SELECT REGISTER
ADDRESS CHANGE:
(\$DFFF TO \$DEFF)



CUT TRACE HERE

MODIFICATION FOR 27256



INSTRUCTIONS FOR PROGRAMMING EPROMS FOR BANK SWITCHING BOARD

This procedure results in up to four programmed EPROMs containing a basic program of up to 38k bytes, with the necessary download and run routine at the beginning of the first EPROM.

STEP 1- LOAD"DOWNLOAD/RUN",8,1 <CR> (or ,1,1 if from cassette).

This loads the auto-boot routine into RAM at 49152.

NEW <CR>

STEP 2- LOAD"PROMOS 1.0 C64",8 <CR> (or LOAD""if PROMOS is on cassette).

Loads 'PROMOS' into the basic area.

STEP 3- POKE56,208 <CR>
RUN <CR>

PROMOS relocates into \$C000 block (behind the auto-boot)

POKE55,0 <CR>
POKE56,160 <CR>

Reset the top of basic pointer.

STEP 4- LOAD"OBJECT PROGRAM",8 <CR>

Load the object program into the basic area.

STEP 5- POKE49161,PEEK(45) <CR>
POKE49162,PEEK(46) <CR>

Stores the start of basic variables pointer in the auto-boot routine for transfer to the first EPROM.

Z <CR>

Zero the PROMENADE C1 programming socket.

STEP 6- Insert the first EPROM. (2764 is assumed.)

⌘ 49152,49327,0,5,7 <CR> (176 bytes)

Programs auto-boot routine into EPROM.

⌘ 2049,10064,176,5,7 <CR> (8016 bytes)

Fills balance of first EPROM with 8016 basic bytes.

STEP 7- Insert the second EPROM into the programmer.

⌘10065,18256,0,5,7 <CR> (8192 bytes)

STEP 8- Insert the third EPROM into the programmer.

⌘18257,26448,0,5,7 <CR> (8192 bytes)

STEP 9- Insert the fourth EPROM into the programmer.

⌘26449,<MEM END>,0,5,7 <CR> (up to 8192 bytes with 2764,
or 16384 bytes with 27128).

Here, <MEM END> = PEEK(45)+256*PEEK(46) -1

STEP 10- Install the first, second, third and fourth EPROMS
into sockets 0, 1, 2, and 3 respectively. The cartridge
is ready for use.

NOTES- The RUN/STOP (keyboard break) is disabled by the auto-
boot routine.

The auto-boot routine checks for EPROM type (2764,
27128, or 27256) and automatically down-loads the proper
data. EPROM types can be mixed and can be used in any
socket. The "⌘" commands must of course contain the proper
memory parameters.

DISASSEMBLY OF DOWNLOAD/RUN ROUTINE

```

:0000 8B      ???
:0001 89      ???
:0002 EC FE 03 LDY  #03FE,X
:0005 C2      ???
:0006 CD 88 80 CMP  #0088
:0009 80      BRK
:000A 22      BRK
:000E 8E 16 D0 STX  #0016
:000F BD 00 80 LDA  #0000,X
:0011 9D 00 02 STA  #0200,X
:0014 17      TAX
:0015 D0 17      BNE  #0015
:0017 4C 1A 08 JMP  #0017
:001A 23 F3 FD JSR  #FD03
:001D 20 58 FD JSR  #FD58
:0020 F5 7E      LDR  #007E
:0022 8D 84 02 STA  #0084
:0025 20 15 FD JSR  #FD15
:0028 20 18 FD JSR  #FD18
:002F 20 58 E4 JSR  #E458
:0032 20 57 E3 JSR  #E357
:0031 89 27      LDA  #0027
:0033 9D 26 06 STA  #0026
:0036 89 7E      LDA  #007E
:0038 9D 29 06 STA  #0029
:003B A2 00      LDX  #0000
:003D 85 01      STX  #01
:003F 85 03      STX  #03
:0041 89 31      LDA  #0031
:0043 85 A3      STA  #A3
:0045 89 37      LDA  #0037
:0047 85 A4      STA  #A4
:0049 80 B0      LDY  #00B0
:004B 20 B0 00 BIT  #00B0
:004F 89 02      LDR  #0002
:0050 85 02      STR  #02
:0052 85 04      STR  #04
:0054 81 01      LDR  (#01),Y
:0055 91 A3      STR  (#A3),Y
:0058 08      INY
:0059 D0 F9      BNE  #0054
:005B E6 A4      INC  #A4
:005D E6 02      INC  #02
:005F A5 02      LDR  #02
:0061 09 98      CMP  #0098
:0063 D0 EF      BNE  #0054
:0065 AD 0A 00 LDA  #000A
:0068 05 A4      CMP  #A4
:006A 90 31      BCC  #006A
:006C D0 07      BNE  #0075
:006E A4 A3      LDY  #A3
:0070 0C 29 02 CPY  #0029
:0073 B0 28      BCS  #006D

```

8000, 8001- Pointer to start of auto-boot routine.

8002, 8003- Pointer to NMI handler.
cbm80- Cartridge identifier.

Will contain pointer to start of basic variables.

For benefit of 'VIC' chip.

Transfer auto-boot routine out of ROM.

Continue in new location.
System initialization.

Set top of memory pointer.

System initialization.

Disable RUN/STOP (keyboard break).

Get ready to down-load basic from ROM.

Down-load 8k segment.

Finished?

```

0075 80 00 LDY ##00
0077 8A TXA
0078 28 03 AND ##03
007A C9 03 CNP ##03
007C F8 13 BEQ #0091
007E 5B INX
007F 8A TXA
0080 29 FC AND ##FC
0082 8D FF DF STA $DFFF
0085 B1 C3 LDR ($C3),Y
0087 8E FF DF STX $DFFF
0088 D1 C3 CNP ($C3),Y
008C D0 BE BNE #004C
008E C8 INY
008F D0 EE BNE #007F
0091 8A TXA
0092 28 3C AND ##3C
0094 18 CLC
0095 59 04 ADC ##04
0097 8A TXA
0098 8E FF DF STX $DFFF
009B D0 AF BNE #004C
009D 85 2E STA $2E
009F 8D 09 00 LDR $C009
00A2 85 2D STA $2D
00A4 85 27 STA $27
00A6 81 FF DF STX $DFFF
00A9 28 59 A6 JSR $A659
00AC 58 CLI
00AD 4C AE B7 CNP $A7AE
00B0 00 BRK
00B1 00 BRK
00B2 00 BRK
00B3 00 BRK
00B4 00 BRK
00B5 00 BRK
00B6 00 BRK
00B7 00 BRK
00B8 00 BRK
00B9 00 BRK
00BA 00 BRK
00BB 00 BRK
00BC 00 BRK
00BD 00 BRK
00BE 00 BRK
00BF 00 BRK
00C0 00 BRK
00C1 00 BRK
00C2 00 BRK
00C3 00 BRK

```

Check for EPROM type and set Bank Select Register to next appropriate value. Then move next 8k segment.

Set start of variables pointer.

Switch out ROM, switch in RAM.

Do 'CLR' and reset stack pointer. Permit normal interrupts. 'RUN' the now down-loaded basic.